

Job Site Preparation



Before Installation

- **All Glazing Is Complete**
- **Glazing Is Clear Of Debris**
No materials in contact with glazing - no tape, paint, protection panels, etc.
- **Workspace Is Clear**
Move any furniture or equipment to create a minimum 3 ft working space.
- **No Dust**
No activity creating dust in the space for 72 hours before install: no sanding, sweeping, grinding, etc.
- **Caulking Is Dried**
Caulking has dried for at least 48 hours.

If Conditions Are Not Met

If instructed to install despite these conditions not being met, we are not responsible for any resulting issues such as: excessive dust or fiber particles trapped under film, or damage to film during the caulking process.



After Installation

Be Mindful Of Work Near The Installed Film

After install, contractor is responsible to protect film. Film needs 30 days to dry and during this period it is critical to be mindful to protect it from tears and damage resulting from furniture moving, window cleaning, or scraping against the film