



Type II Wall Covering

Turn over for Adhesive Back

Wall Surface Preparation for Type II Wall Covering

- ① Level 5 wall recommended
- ② Remove any loose paint from the wall
- ③ Prime wall with two coats of Glidden Multi-Purpose Gripper Primer
- ④ Allow primer to sit for **36 hours** before install

If You Have Any Questions, Please Contact Us!

562.426.7701

hello@metwest.com



Adhesive Back

Turn over for Type II Wall Covering

Wall Surface Preparation for Adhesive Back Wall Covering

- ① Level 5 wall recommended
- ② Remove any loose paint from the wall
- ③ Prime wall with Glidden Multi-Purpose Gripper Primer and apply a semi-gloss paint
- ④ Clean wall using lint free cloth and solution of 70% Isopropyl Alcohol and 30% water

If You Have Any Questions, Please Contact Us!

562.426.7701

hello@metwest.com