

Window Film And Graphic Cleaning Instructions

To obtain maximum service from your window film products please note the following care instructions.



Drying Time

During the film installation, the installer will remove as much of the installation fluid as possible, but a small amount will still remain. This may result in small water bubbles appearing and/or a slightly cloudy view. This is normal and should be expected. Do not pierce the water bubbles during this drying period. This damage to the window film will not be covered by the warranty. The water bubbles and cloudy view will disappear over time.

Film type and climate conditions will determine the drying time you experience. Warm weather and direct sunlight will shorten the drying time, while cooler climates, cloudy conditions and thicker films may prolong it. Drying may vary from a few days to 6 months for thicker safety films. The trapped moisture will dry out completely.



Cleaning

Do not clean the window film for 30 days after it is installed. A soft cloth, squeegee or synthetic sponge is recommended for cleaning the window film. Do not use bristle brushes, abrasive scrubbing sponges or any other cleaning materials that could scratch the film or that may have been contaminated with dirt particles. This can happen when washing interior and exterior windows with the same cleaning materials. Some brands of paper towels are coarse enough to put fine scratches in the film. While these scratches may be too thin to be seen initially, they can damage the polished look of the film over time. Always use fresh, clean, soft material to wash and dry your window film surfaces.

The best cleaning method is to use 1 teaspoon (5 ml) of liquid detergent mixed with 1 quart (liter) of water. We do not recommend degreasing agents or detergents containing alcohol, acid or ammonia. A soft cloth or sponge is recommended for washing the window, followed by another soft cloth or rubber squeegee to dry the film.